

D900 SERIES PUSHBUTTON LOCKS

SECURITY AND DURABILITY IN AN AFFORDABLE PACKAGE

The Illinois Lock pushbutton lock is factory set with a combination of: First push #2 and #4 together, and then #3. Always turn the knob counter-clockwise, to clear, before entering the combination. If any of the buttons had been pushed previously, this clears and reactivates the buttons.

To Unlock:

- 1) Turn the knob counter-clockwise to the clear position and release (the knob will spring back to the lock position). This will activate all the buttons.
- 2) Enter the current combination by pressing the buttons in the proper sequence.
- 3) Turn the knob clockwise to the unlock position.

To Lock:

- 1) Turn knob counter-clockwise to the clear position and release (the knob will spring back to the lock position).



To Change Combination:

It is easy to change to a new combination, using one, all five, or any number of buttons in any order. Two or more buttons may be pushed at a time as part of the new combination. Each button can only be pushed once in establishing the combination. Record your combination, and keep it in a safe place.

- 1) Open lock (use current combination or key override).
- 2) Rotate knob to the clear position and release (the knob will spring back to the lock position).



- 3) Enter current combination.



- 4) Depress reprogram button (marked red) on backside of lock.



- 5) Rotate knob to the clear position and release (the knob will spring back to the lock position). This clears the current combination.



(continued on back)